


Intended use


This stationary UHF RFID reader model: ASSY OVR RFID is an UHF RFID tag reader intended to be used in stores at check-out and store exits for detecting and reading of UHF RFID tags.



Warning

This equipment should be installed, operated, serviced, and repaired by skilled personnel only. The installation and interconnection of this equipment to facility wiring and other equipment must be done by a competent, skilled craftsperson who is familiar with applicable standards and codes governing the installation. Installation methods, practices or procedures that are unauthorized or done improperly are dangerous and could result in serious personal injury or damage to property and equipment.







Nedap N.V.

Parallelweg 2, NL-7141 DC Groenlo (The Netherlands)

Mail: support-retail@nedap.com

dsgn : CvdB date

: 26 January 2024 9:12 am


:9982191





document: T9982191-45.01


revision : A.04


Copyright © Nedap N.V. No part of this document may be reproduced, copied or distributed in any form or by any means, or stored in a database or retrieval system, without the prior written permission of Nedap N.V.




















Renos

50Ω Connect to the 50Ω PCB from the antenna. 1. Lights / IR Connect to the lights and customer counting.

Add-on Provide power and synchronisation to add-ons, like the RFID reader. 3.

Network IN Connected to the Network OUT of a previous Renos unit or a Power Inserter. Connect accessories to Renos, like the RFID reader or USB network adapter. USB 5.

Network OUT Connected to the Network IN of a previous Renos unit or a Power Inserter.

Can also be left unconnected or connected to the customer network.

7. Mini USB service port Connect your laptop to configure the Renos system.

RS485 connector Connect to the smart deactivator(s).

Connect to the buzzer. Buzzer connector

Status LEDs Renos

1.	Green	On	There is a Renos unit connected to the OUT port of this unit
	0.1	Off	There is no Renos unit connected to the OUT port of this unit
2.	Blue	Blinking	There is no device connected to the OUT port of this unit
		On	There is a Power Inserter connected to the OUT port of this unit
3.	Red	On	There is an issue with the power supply at the OUT port of this unit (too little current drawn)
		Blinking	There is an issue with the power supply at the OUT port of this unit (too much current drawn)
		Off	There is no issue with the power supply at the OUT port of this unit
4.	Yellow	Blinking	The operating system on the Renos unit is running
		Off	The operating system on the Renos unit is not running
5.	Green	Blinking	The storage flash on the Renos unit is accessed
		Off	The storage flash on the Renos unit is not accessed
6.	Green	On	The firmware on the Renos unit is running
		Off	The firmware on the Renos unit is not (yet) running

Status LEDs RFID Reader

1.	Blue	On	The RFID Reader is connected to the Renos firmware
		Blinking	The RFID Reader has received a command from the Renos firmwar
		Off	The RFID reader is not connected to the Renos firmware
2.	Orange	Blinking slow	The firmware on the RFID Reader is running
		Off	The firmware on the RFID reader is not running
3.	Red	On	There is an error with the RFID output
		Off	There is no error with the RFID output
4.	Green On	On	The RFID output is active
		Blinking	The reader is reading RFID labels
		Off	The RFID output is not active
5.	Green	On	The RFID reader is powered by the Renos unit



Specifications

Brand - Nedap

Model - ASSY OVR RFID - 56VDC Power-over-Ethernet (PoE) **Power Supply**

Power consumption - Max. 13W

Off

Dimensions - 372mm x 372mm x 81mm

Weight - 4.0kg Operating temparature - 0°C - 45°C

Antennas - Internal quad-patch antennas Mounting - Ceiling or wall mounting

Alarm signaling - Audible and multi color light

Region 1 frequency band - 865 - 867MHz Channels, spacing, power - 4, 750kHz, 2W ERP

Disposal of this product



6.

The owner or last user of this product is responsible for proper disposal of (parts of) the product as required by local rules and regulations.

The RFID reader is **not** powered by the Renos unit

CE - UKCA declaration of Conformity

Hereby, Nedap N.V. declares that the equipment model ASSY CO252R RF is in compliance for CE with directives 2014/53/EU (Radio Equipment Directive) and 2011/65/EU (RoHS). And for UKCA with SI 2017/1206 (radio Equipment Regulations 2017) and with SI 2012/3032 UK Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (RoHS). The full text of the declarations of conformity is available at following internet address: https://portal.nedapretail.com/, where, if applicable, also REACH information can be found



Disclaimer

Nedap intends to make this manual accurate and complete. However, Nedap does not warrant that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. Nedap disclaims any liability for damage to property or personal injury resulting, in whole or in part, from improper installation, modification, use or misuse of its products. The information contained in this document is subject to change without notice.

User manual

The complete instruction manual can be found at https://portal.nedapretail.com/

FCC and IC Compliance statement

This device complies with part 15 of the FCC Rules and to RSS210 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Cet appareil se conforme aux normes CNR 210 exemptés de license du Industry Canada. L'opération est soumis aux deux conditions suivantes:

- (1) cet appareil ne doit causer aucune interférence, et
- (2) cet appareil doit accepter n'importe quelle interférence, y inclus interférence qui peut causer une opération non pas voulu de cet appareil. Les changements ou modifications n'ayant pas été expressément approuvés par la partie responsable de la conformité peuvent faire perdre à l'utilisateur l'autorisation de faire fonctionner le matériel.

FCC and IC Radiation Exposure Statement

This equipment complies with FCC and Canadian radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 5 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme a CNR-102 limites énoncées pour un environne- ment non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 5 cm entre le radiateur et votre corps. This Class B digital apparatus complies with Canadian ICES-003 Cet appareil numérique de Classe B est conforme à la norme Canadienne ICES-003.

FCC Information to the user

Note: This equipment has been tested and found to comply with the limits for a class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequent energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determine by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver.

NOTE: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. To ensure compliance with FCC regulations, use only the shielded interface cables provided with the product, or additional specified components or accessories that can be used with the installation of the product.

Warranty and spare parts

Please consult the Nedap products dealer from whom you purchased this product, in regards to the applicable warranty conditions. This product cannot be used for any other purpose as described in this document. If the product is not installed according to this document; the warranty provided is not applicable. At the sole discretion of Nedap N.V., Nedap N.V. may decide to change the conditions of the Page 7 of 19 Compliance information for technical manuals warranty policy. You agree that Nedap N.V. is able to compensate you the pro-rata value of the warranty involved rather than replacing or repairing the product depending on the technical or economical value of the product. Prior to applying the warranty, please verify if you comply with the warranty conditions of the warranty policy, whether you can successfully apply for the replacement or repair of a defective part. Parts can only be replaced with original Nedap parts, otherwise the warranty policy will not be applicable on the product. If the warranty is applicable, please contact the dealer or send the defective parts to the dealer.



Information for Taiwan

第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信; 經發現有干擾現象時,應立即停用,

並改善至無干擾時方得繼續使用。,前項合法通信, 指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、 科學及醫療用電波輻射性電機設備之干擾。

